

Wiring a door sensor to the AXIS 2014E for use with Doorcam.io

The AXIS 2014E has two main parts: The camera part and the main body part. On the main body part there is an I/O port. Attach the door sensor to ports 1 + 3.



Figure 1: Door sensor wiring for AXIS 2014E

Run a cable (multicore alarm cable is adequate and low cost) from the I/O port to the door sensor.

Note: The voltage for the door sensor is provided by the AXIS 2014E. There is no need for any additional power supply.



Figure 2: Most simple door sensors will suit

Most simple door sensors will work with the system. For example:

<http://uk.rs-online.com/web/p/security-alarm-door-window-switches/1220715/>

Contact us on info@eyespyfx.com for further information about how Doorcam.io can be deployed in a variety of circumstances.